

Clearviews Glass French Balcony Installation Instructions

1. Line up bottom track to be horizontally center with the window opening.
2. Line up bottom track vertically to allow the access to the glazing bead from the inside.
3. When properly lined up fasten the bottom track brackets firmly to the wall. (use a level to make sure you are horizontally level)
4. Measure the correct height of the handrail position (Use the Clearviews Section Drawing in the downloads section)
5. Center the handrail to be center with window/equal overlap on the two sides.
6. When properly lined up fasten the handrail firmly to the wall through the brackets
7. Remove bottom glazing bead if in place.
8. Place two spacers on the bottom track for each glass and use a dab of silicone to hold them in place.
9. Remove any stickers/writing/spacers that are stuck on the glass.
10. Put the glass panes in place by inserting them into the slot in the handrail and lowering them onto the spacers.
11. Replace the glazing bead in the bottom rail.
12. Line the glass panes up in position so that they are spaced correctly between each other/ wall etc.
13. Insert the 1/8" (3mm) rubber gasket in the bottom track between the glass and the glazing bead. (using soap water can ease the process)
14. Insert the two 1/8" (3mm) rubber gaskets on both sides of the handrail. (using soap water can ease the process)
15. Trim off excess rubber.